

SP-1100 All-in-One Conference Camera

Quick Setup Guide

快速安裝指南




CAVE-TEK LTD.
sales@cave-tek.com
www.cave-tek.com




Package Details


產品內容



SP-1100 CAMERA
攝影機



REMOTE CONTROL
遙控器



WALL MOUNT KIT
壁掛包




SETUP GUIDE
安裝指南




USB CABLE
USB線

Overview 產品介紹

Physical 外觀介紹




FRONT
正面



BACK
背面

Remote Control 遙控器




No.	Name	Function Description
1	Camera Close Key	Press to turn off the camera, press again to resume
2	Call Key	Answer the call
3	Camera Direction Keys	Press to move the camera to up, down, left and right direction to adjust the image display; press the [OK] key to return the camera to the middle position
4	Volume +/- Keys	Press to increase or decrease the volume
5	Exit Tracking Key	Press to exit the tracking mode
6	Speaker Tracking Key	Press to perform voice tracking of the speaker
7	Preset 1 Key	Long press to set preset 1; short press to call preset 1
8	Preset 2 Key	Long press to set preset 2; short press to call preset 2
9	Standby Key	Long press to switch the camera to standby mode; short press to resume
10	Hang Up Key	Hang up the call
11	OK Key	Confirm selection
12	Mute Key	Turn on/off the microphone
13	Zoom Keys	Zoom in the lens [+]; Zoom out the lens [-]
14	Speaker Mute Key	Turn on/off the speaker
15	Participants Tracking Key	Press to track the participants automatically
16	Menu Key	Press to enter or exit the OSD menu


Quick Setup Guide

快速安裝指南


1. Install 安裝




Fix bracket on the wall



Screw Lock



Fix camera on the bracket





Wall-mounted effect picture

Place the camera on the table or on the wall.

將攝影機安裝於桌上,牆上.


2. Connect 連接



Connect the USB cable to your computer, or (and) the HDMI cable to display.

連接 USB 至電腦, 連接HDMI至顯示器.

3. Config 設定



Configure the SP-1100 USB Camera, Microphone, and Speaker on your laptop.
將電腦設定到SP-1100 攝影機,喇叭,麥克風.

Switch the tracking mode on the remote. (Off/Speaker/Participants)
切換追蹤模式(關閉/發言者/參與者).