

# CAVE NSR-400 Hybrid Recorder

## Quick Setup Guide

## 快速安裝指南




CAVE-TEK LTD.  
sales@cave-tek.com  
www.cave-tek.com




# Package Details

## 產品內容

### Package 包裝內容



**NSR-400 DEVICE**  
錄影直播盒



**POWER ADAPTOR**  
變壓器



**SETUP GUIDE**  
安裝指南

### Physical 外觀介紹




**FRONT**  
正面




**BACK**  
背面

# Quick Setup Guide 快速安裝指南

## 0. Basic Usage 基本使用情境




## 1. Install 安裝



# Quick Setup Guide (2)


## 快速安裝指南 (2)

### 2. Power On 開機



To open the admin page, right-click the mouse. Alternatively, you can enter the web admin page from your laptop.

按下滑鼠右鍵開啟管理介面,或透過網路進入管理頁面。



- Default IP: **192.168.100.200**
- Account/Password: **admin / 0000**

### 3. Config 設定



**Primary Source**  
選取主要畫面來源

- [Source]: Select HDMI (or IP stream) for input 1/2/3/4.
  - [Record]: Configure the recording settings.
  - [Streaming]: Configure the recording settings.
  - [PGM]: Configure the Full screen, QuadView, PBP, or PIP for the mixed screen.
- [影像來源]: 選擇HDMI訊號 (或IP串流) 當作訊號1/2/3/4來源
  - [錄影]: 設定錄影參數.
  - [串流]: 設定串流參數.
  - [導播]: 選擇全畫面拼接模式, 四分割, PBP或是PIP模式. 並選擇主要畫面來源.

### 4. Start Recording / Streaming 開始錄影/直播

Press the "Record" button to start recording, and the "Streaming" button to start streaming.

按下"Record" 及"Streaming" 按鈕開始錄影與直播.