

1080P USB PTZ Camera (A12)

Quick Setup Guide 快速安裝指南




CAVE-TEK LTD.
sales@cave-tek.com
www.cave-tek.com




Package Details

產品內容




PTZ CAMERA

攝影機



REMOTE CONTROL

遙控器




POWER ADAPTOR

變壓器



SETUP GUIDE

安裝指南




USB CABLE


USB線

Overview 產品介紹

Physical 外觀介紹




FRONT
正面



BACK
背面

Remote Control 遙控器




Item	Name	Description	說明
1	Power Key	Power on / Power-Saving.	關閉攝影機進入待機狀態
2	Number Key	Set / Go to the preset position.	設定預設點/攝影機轉到該預設點
3	*Key	Function key. (*)	功能鍵 (*)
4	Preset Key	Set preset: Store a preset position. SET Preset: [SET PRESET] + Numeric (0-9)	設定/儲存預設點 設定預設點: [SET PRESET] + Number 鍵 (0-9)
5	HOME Key	Confirm Settings / Restore to the default position.	儲存設定/將攝影機回復到預設點
6	Return Key	Go back to the previous level	回上一層
7	Zoom Key	Slow Zoom In [+] or Zoom Out [-] Fast Zoom In [+] or Zoom Out [-]	慢速 Zoom In [+] or Zoom Out [-] 快速 Zoom In [+] or Zoom Out [-]
9	Focus Key	Switch the focus setting	切換 focus 模式
10	Camera Select	Select the target camera	選擇要控制的攝影機
11	#Key	Function key. (#)	功能鍵 (#)
12	IR Remote Control Key	[*]+[#]+[F1]~[F4]: Address 1, 2, 3, 4	[*]+[#]+[F1]~[F4]: 設定攝影機 1~4 位置
13	Reset Key	Erase a preset position setting. [RESET] + Numeric button (0-9)	清除預設點設定 [RESET] + Number 鍵 (0-9)
14	PTZ Control Key	Press arrow buttons to perform camera panning and tilting.	按下箭頭按鍵進行攝影機鏡頭水平 / 垂直移動
15	Menu Key	Enter or exit the OSD menu.	進入或離開 OSD Menu 選單
16	Backlight Key	Enable/Disable the backlight compensation.	啟動或停用背光補償.
Function Key	Name		Description
	Description		說明
	[*]+[#]+[1]		Show English Menu
	[*]+[#]+[3]		Show Chinese Menu
	[*]+[#]+[4]		Show IP Address
	[*]+[#]+[6]		Reset System
	[*]+[#]+[8]		Show FW Info.
Function Key	[*]+[#]+[9]		Set Vertical flip
	[*]+[#]+[MANUAL]		Set to DHCP mode


Quick Setup Guide

快速安裝指南

1. Install 安裝




Ceiling Mounting.
(Optional)
天花板吊掛方式.
(吊掛架選配)



Wall Mounting.
(Optional)
壁掛方式.
(壁掛架選配)


Place the camera on the table or place the camera on the wall or ceiling.
將攝影機安裝於桌上,天花板或是牆壁.

2. Connect 連接



Connect the USB cable to your computer and (or) the network cable to the video streaming server.

連接 USB 至電腦. 並連接網路線至串流主機



Connect the audio cable, RS-232 cable, and network to the external system.

連接音源線, RS-232線至外部系統. (非必要)

3. Power On 開機

Turn on the camera and the camera head will rotate to the default position.

開啟攝影機電源,攝影機鏡頭將開始轉動至預設位置.